

JONATHAN PICKUP

VECTORWORKS ARCHITECT





Jonathan Pickup | seventh edition written with version 2015



Archoncad

Architecture on CAD, Ltd.

10 Laws Place
Napier, New Zealand
T +64 217 43470
jon@archoncad.com
twitter: twitter.com/archoncad

© 2015 Jonathan Pickup - Archoncad

All rights reserved. No part of this book may be reproduced or transmitted in any form by any means, electronic or mechanical, including photocopying, recording, faxing, emailing, posting online, or by any information storage and retrieval system, without prior written permission of the publisher. Published in the United States.

Vectorworks is a registered trademark of Nemetschek Vectorworks, Inc., in the United States and other countries. Windows is a registered trademark of Microsoft Corporation in the United States and other countries. Macintosh is a trademark of Apple Computer, Inc., registered in the United States and other countries. Adobe, Acrobat, and Reader are registered trademarks of Adobe Systems in the United States and other countries.

The information in this book is distributed on an "as is" basis, without warranty. While every precaution has been taken in the preparation of this book, neither the author nor Nemetschek Vectorworks shall have any liability to any person or entity with respect to any loss or damage caused or alleged to be caused directly or indirectly by the information contained in this book or by the computer software described in it.

For more Vectorworks training information or to purchase more copies of this book, please visit www.Vectorworks.net/training, or call us at (410) 290-5114.

There are several people I would like to thank: Mike Moore, Steve Scaysbrook, Roger Williams, and Bill Vincent. Without them, none of my manuals would be as good as they are.

A big thank you to my wife, Marie, and my kids. I need your support and understanding to spend the hours required to create these manuals.


Jonathan, January 2015

Table of Contents


Introduc	ction: How to Use this Manual	iii
	New Ways of Drawing	
	Vectorworks Architect Workflow	iv
Step 1	File Setup	1
	Document Setup	
	Text Styles	
	Custom Dimension Standard	10
Step 2	Property Line	13
otep 2		10
Step 3	Layer (Model) Setup	17
Step 4	Creating the Site Model	29
	What is a Site Model?	
	How Does It Work?	30
	What Can You Do with Site Modeling?	
	Different Methods of Making a Site Model	
	Creating a Layer for the Scanned Image	
	Creating the Site Model	
	Height in Relation to Boundary	
Step 5	Quick Bulk and Location	61
	Creating the Lower Floor	61
	Creating the Upper Floor	
	Linking Spaces to the Site Plan	72
Step 6	Concept Drawings	89
	Preparation	
	Plan Viewport	
	Perspective Viewports	
Step 7	Creating the Walls	QO
	Creating Basement Walls	
	Creating Dasement Walls Creating Other Wall Styles	
	Demolished Walls	
	Proposed Walls	
	Internal Walls	110

	Drawing Upper Walls	117
	Check the Walls on the Site Plan	
Step 8	Creating the Roof	129
	Existing Roof	129
	Proposed Roof 1	
	Proposed Roof 2	137
	Fitting Walls to Roof	148
Step 9	Developed Design Drawings	151
Step 10	Doors and Windows	165
	Standard Vectorworks Doors and Windows	
	Adding New Doors	
	Creating Corner Windows	180
	Creating a Window Schedule	182
	Editing the Window Schedule	183
	Updating the Concept Plan	186
Step 11	Site Modifiers	191
	Roads	192
	Pads and Grade Limits	199
Cton 10	Chaire	207
Step 12	Stairs	207
Step 13	Annotation.	219
	Standard Title Blocks (Drawing Border)	
	Drawing Labels	
	Notes, Keynotes, and Callouts	
Step 14	Working Drawings	233
	Drawing 01 - Site Plan	
	Drawing 02 - Foundation Plan	
	Drawing 03 - Framing Plan	
	Other Drawings	

When you start Vectorworks Architect, it looks like this on a Windows machine:




When you start Vectorworks Architect, it looks like this on a Macintosh:



Step 1 File Setup

Document Setup

We will set up the file from the beginning, from a blank document. Vectorworks has set up commands to make it easier to set up the file. When you have set up the file, it can become a template file that you can use to start every new job, saving you a lot of setup time.



- Go to the Menu bar.
- Choose File > Page Setup...

This opens a dialog box for you to set up the page size.

This dialog box allows you to set up the printer that you are using.

Click on the Printer Setup... button.

This dialog box will vary depending on your printer.

- On a Macintosh, the dialog box will look similar to this picture. Set the printer, page size, and page orientation.
- Click on the **OK** button.
- On a Windows machine, the dialog box will look similar to this picture. Set the printer, page size, and page orientation.
- · Click on the OK button.









This takes you back to the Page Setup dialog box.


Our drawings are going to be set up using Viewports, so the page boundary won't be meaningful on our design layers.

- Turn off Show Page Boundary.
- · Turn off Show Page Breaks.
- Click on the OK button.

Vectorworks shows the new drawing area.

The reference grid may not appear on the screen due to the density of the grid at a particular scale and page size.








- · Go to the Menu bar.
- Choose File > Document Settings > Document Setup...

Document Setup is a quick way to set up the drawing when you are starting a new project.




In this dialog box we get the opportunity to check the setup of the project as a whole: the units, layer scale, drawing area, grid setting, and the title block size.


Click on the Drawing Units:
 Change... button. This will open the Units dialog box for us to set up the drawing units, primary dimensioning, secondary dimensioning, and area and volume units.









The settings might be in feet and inches.



 Set the Dual Dimensions (secondary units) to the settings that you want.




- You can mix the dimensions types with the Dual Dimensions.
- Click on the OK button.








- Set your Layer Scale to 1:200 for metric drawings or 1/16 (1:192) for imperial drawings. We will start by drawing the site plan, so this scale should be suitable.
- Click on the **OK** button.
- Click on the Drawing Grids:
 Change... button. This will open the Set Grid dialog box for us to set the snap and reference grids for our file.





- · Choose General on the left-hand side.
- Set the option as shown on the image.

- · Choose Grid on the left-hand side.
- For metric drawings, set the snap grid to 100mm and the reference grid to 1000mm.
- For for imperial drawings, set the snap grid to 4" and the reference grid to 3'.
- Click on the OK button.





The reference grid may not appear on the screen due to the density of the grid at a particular scale and page size.

The Document Setup dialog box now shows you your setup.

Click on the **OK** button.



Text Styles

Text styles allow you to create settings for the text you want to use, like paragraph styles in a word processor. This will allow you to define the text settings for a particular style of text and save it. Then you can apply the same style to other text that you want to look the same. When you edit the text style, all the objects with the same text style will update.



- Go to the Menu bar.
- Choose Text > Format Text...



 Chose the font, size, and other text settings you want for a dimension.
 Text styles allow us to assign these settings to our dimensions.

It is easier if you create the text style first.

· Click on the Save... button.



- Name the text style to make it easy to find.
- · Click on the OK button.




You can see the name of the text style at the top of the dialog box. If you make a mistake, do not worry: I'll show you how to edit the style later.



• Click on the **Style** drop-down menu. The text styles above the gray line are in the current file, and the text styles below it are default text styles that come with Vectorworks.


· Click on the **OK** button to finish.




Text styles appear in the Resource Browser.



- Right-click (Control + click) on the text style in the Resource Browser to modify a text style.
- · Choose Edit...



- · Make any changes you want.
- Click on the **OK** button to confirm the changes. Every object that uses this text style will update.



Custom Dimension Standard

Vectorworks comes with several typical dimension standards. That is fine if you like the standard settings, but if you want something custom, you can make it.

- · Go to the Dims/Notes tool set.
- Click on the Constrained Linear Dimension tool.






Go to the **Tool** bar.

The current dimension standard is shown on the **Dim Std:** drop-down menu.

- · Click on the drop-down menu.
- Choose Custom Standards...







- Click on the **New...** button to create a custom dimension standard.
- · Name the custom dimension standard.
- Click on the **Edit...** button to edit the standard.




• Change the dimension settings to suit your drawing style.



- Click on the **Text Style** drop-down menu.
- Choose the text style we created for dimensions.



 Click on the **OK** button to return to the Custom Dimensions dialog box.



Click on the OK button.



- · Go to the Tool bar.
- Choose your new dimension standard from the drop-down menu. From now on, every time you place a dimension, you will be using your text style and dimension standard.
- To save your file as a template, go to the Menu bar and choose File > Save as Template...



Jonathan Pickup | seventh edition

VECTORWORKS ARCHITECT Tutorial Manual

written with version 2015

ABOUT THE AUTHOR

Jonathan Pickup is an architect trained in New Zealand and in the United Kingdom with more than 25 years of experience. He received his Bachelor of Architecture (BArch) degree from the University of Auckland in New Zealand. He later spent more than eight years in England where he learned to use several CAD packages, including MiniCad, and began teaching this forerunner of Vectorworks. Upon returning to New Zealand in 1997, he established archoncad, a Vectorworks training and consulting company. He has written several Vectorworks training manuals for architects, landscape architects, educators, and design students. He organizes the New Zealand Vectorworks User Group and provides its main director.

VECTORWORKS ARCHITECT is a powerful addition to the Vectorworks family of design software. This tutorial manual is based on Jonathan Pickup's successful Vectorworks Architect course taught in New Zealand. The feedback from this course has been very positive and has helped many clients to use Vectorworks Architect and, just as importantly, to develop an office drawing system based on Vectorworks organizing concepts.

This exercise-based tutorial manual covers

- basic concepts of layers and classes and how they relate to developing your office layer and class standard.
- · creating an office library.
- · using the Property Line tool.
- creating and manipulating site models and using them for height-to boundary analysis.

- walls and the wall type library.
- stairs and vertical transport.
- how to make a quick model of a project using spaces for bulk and location analysis.
- using annotation tools, title blocks, and the note database to quickly annotate your plans.

\$75.00 ISBN 978-1-940194-06-6 57500

NVM.ARC-2015 v1.0 Cover imagery courtesy of Brian Kendrick, ENVISIONS ArchiMedia